

# DS-1 Instruction Manual

## KEYBOARD



**RED Button** \* Turn the scale ON.  
\* Only when the scale shows "0.0g" can it be turned OFF  
\* "0" balance adjust  
The value showing on the scale can be tared to "0.0g" by pressing when indication of the screen is other than "0.0g" during stylus presser measurement.

**BLUE Button** \* Measure unit

g	gram
oz	ounce (1oz $\doteq$ 28.35g)
dwt	pennyweight (dwt=24gn)
ozt	troy ounce (1toz=20dwt)
gn	grain (gn $\doteq$ 64.8g)
Ct	carat (1ct=200mg)

## MEASUREMENT

- Insert batteries and place the scale on the turntable platter then push RED button.
- The scale will display "8888" on the screen. After 3 to 6 seconds, it will be read "0.0g" which means the scale is in weighting state.
- Then put stylus on the center of tongue of the above ① in illustration.
- Will display the number, it is stylus pressure value.
- After measured and 60 second later, it will be automatically shut off.

## MAINTENANCE

- When it is displayed "LO" on the screen, it becomes time to change the batteries ( 2 x CR2032 lithium battery)
- When it is took out from the case cover, please do not pull by tongue.

**ortofon**

Ortofon Japan Co., Ltd.  
2-2-6, Yushima, Bunkyo-ku, Tokyo, Japan  
Ortofon A/S  
Stavangervej 9, 4900 Nakskov, Denmark